



ROUTINE JACK MAINTENANCE BULLETIN

RJM 167

1 OF 1

TO PROVIDE COMPLETE INFORMATION ON SERVICING AND ColumbusJACK/REGENT QUALITY GROUND HANDLING EQUIPMENT

SUGGESTED PREVENTATIVE MAINTENANCE FOR MODEL 7054-010 JACK TESTER

To ensure that Model 7054-010 Static Jack Tester is in proper operational condition, it is recommended that the following preventative maintenance procedures be conducted.

Prior to Each Use

- 1) Check structure for any signs of damage.
- 2) Check all bolt connections to ensure tightness.
- 3) Check electrical cables for damage or loose connections.

Every 6 Months

- 1) Inspect hoist components per manufacturers instructions and verify hoist operates freely.
- 2) Inspect for corrosion on structural components.

Annually

- 1) Verify load cell calibration.
- 2) Lubricate chain hoist per manufactures instructions.