



ROUTINE JACK MAINTENANCE BULLETIN

RJM 168

1 OF 1

TO PROVIDE COMPLETE INFORMATION ON SERVICING ColumbusJACK/REGENT QUALITY GROUND HANDLING EQUIPMENT

SUGGESTED PREVENTATIVE MAINTENANCE FOR MODEL 8556-010 JACK TESTER

To ensure that Model 8556-010 Static Jack Tester is in proper operational condition, it is recommended that the following preventative maintenance procedures be conducted.

Prior to Each Use

- 1) Check structure for any signs of damage.
- 2) Check all snap rings for proper installation.

Every 6 Months

- 1) Inspect all links, pins and snap rings for damage.
Replace as required.
- 2) Inspect for corrosion on structural components.